### Bioengineering 280A Principles of Biomedical Imaging

Fall Quarter 2008 MRI Lecture 7

Thomas Liu, BE280A, UCSD, Fall 2008

# Phase of Moving Spin $\Delta B_z(x) \longrightarrow x$ $\Delta B_z(x) \longrightarrow x$ time

### **Moving Spins**

So far we have assumed that the spins are not moving (aside from thermal motion giving rise to relaxation), and contrast has been based upon  $T_1$ ,  $T_2$ , and proton density. We were able to achieve different contrasts by adjusting the appropriate pulse sequence parameters.

Biological samples are filled with moving spins, and we can also use MRI to image the movement. Examples: blood flow, diffusion of water in the white matter tracts. In addition, we can also sometimes induce motion into the object to image its mechanical properties, e.g. imaging of stress and strain with MR elastography.

Thomas Liu, BE280A, UCSD, Fall 2008

### Phase of a Moving Spin

$$\begin{split} \varphi(t) &= -\int_0^t \!\! \Delta \omega(\tau) d\tau \\ &= -\int_0^t \!\! \gamma \Delta B(\tau) d\tau \\ &= -\int_0^t \!\! \gamma \vec{G}(\tau) \cdot \vec{r}(\tau) d\tau \\ &= -\gamma \int_0^t \!\! \left[ G_x(\tau) x(\tau) + G_y(\tau) y(\tau) + G_z(\tau) z(\tau) \right] \!\! d\tau \end{split}$$

### Phase of Moving Spin

Consider motion along the x-axis

$$x(t) = x_0 + vt + \frac{1}{2}at^2$$

$$\varphi(t) = -\gamma \int_0^t G_x(\tau) x(\tau) d\tau$$

$$= -\gamma \int_0^t G_x(\tau) \left[ x_0 + v\tau + \frac{1}{2} a\tau^2 \right] d\tau$$

$$= -\gamma \left[ x_0 \int_0^t G_x(\tau) d\tau + v \int_0^t G_x(\tau) \tau d\tau + \frac{a}{2} \int_0^t G_x(\tau) \tau^2 d\tau \right]$$

$$= -\gamma \left[ x_0 M_0 + v M_1 + \frac{a}{2} M_2 \right]$$

Thomas Liu, BE280A, UCSD, Fall 2008

### Phase of Moving Spin

$$\varphi(t) = -\gamma \left[ x_0 M_0 + v M_1 + \frac{a}{2} M_2 \right]$$

$$M_0 = \int_0^t G_x(\tau) d\tau$$

Zeroth order moment

$$M_1 = \int_0^t G_x(\tau) \tau d\tau$$


First order moment

$$M_2 = \int_0^t G_x(\tau) \tau^2 d\tau$$

Second order moment

Thomas Liu, BE280A, UCSD, Fall 2008

### Flow Moment Example



$$M_{0} = \int_{0}^{t} G_{x}(\tau) d\tau = 0$$

$$-M_{1} = \int_{0}^{t} G_{x}(\tau) \tau d\tau$$


$$= -\int_{0}^{T} G_{0} \tau d\tau + \int_{T}^{2T} G_{0} \tau d\tau$$

$$= G_{0} \left[ -\frac{\tau^{2}}{2} \right]_{0}^{T} + \frac{\tau^{2}}{2} \right]_{T}^{2T}$$

$$= G_{0} \left[ -\frac{T^{2}}{2} + \frac{4T^{2}}{2} - \frac{T^{2}}{2} \right] = G_{0}T^{2}$$

Thomas Liu, BE280A, UCSD, Fall 2008

### Phase Contrast Angiography (PCA)



$$\varphi_1 = -\gamma v_x M_1 = \gamma v_x G_0 T^2$$





$$\varphi_2 = -\gamma v_x M_1 = -\gamma v_x G_0 T^2$$



$$\Delta \varphi = \varphi_1 - \varphi_2 = 2\gamma v_x G_0 T^2$$

$$v_x = \frac{\Delta \varphi}{2G_0 T^2}$$






## **Aliasing Solutions** velocity not aliased Use data from regions with slower flow velocity aliased Use multiple VENC values so that the phase differences are smaller than $\pi$ radians. Thomas Liu, BE280A, UCSD, Fall 2008

# Aliasing in PCA


Define VENC as the velocity at at which the phase is 180 degrees.

$$VENC = \frac{\pi}{\gamma G_0 T^2}$$

Because of phase wrapping the velocity of spins flowing faster than VENC is ambiguous.





Thomas Liu, BE280A, UCSD, Fall 2008





During readout moving spins within the object will accumulate phase that is in addition to the phase used for imaging. This leads to

- 1) Net phase at echo time TE =2T.
- 2) An apparent shift in position of the object.
- 3) Blurring of the object due to a quadratic phase term.










### Cerebral Blood Flow (CBF)


CBF = Perfusion


= Rate of delivery of arterial blood to a capillary bed in tissue.


Units: (ml of Blood)
(100 grams of tissue)(minute)


Typical value is  $60 \text{ m}^{1}(100\text{g-min})$  or  $60 \text{ m}^{1}(100 \text{ ml-min}) = 0.01 \text{ s}^{-1}$ , assuming average density of brain equals 1 gm/ml


































































































### **Timeline**

Michael Crichton, 1999

"Most people", Gordon said, "don't realize that the ordinary hospital MRI works by changing the quantum state of atoms in your body ... But the ordinary MRI does this with a very powerful magnetic field - say 1.5 tesla, about twenty-five thousand times as strong as the earth's magnetic field. We don't need that. We use Superconducting QUantum Interference Devices, or SQUIDs, that are so sensitive they can measure resonance just from the earth's magnetic field. We don't have any magnets in there".

Thomas Liu, BE280A, UCSD, Fall 2008

J. Clarke, UC Berkeley

